




1. Drill hole of sufficient depth using same diameter DFS bit as anchor being installed.



2. Turn nut on anchor as required. May be flush with top, or continue turning to provide stud finish.



3. With nut, washer and drive pin in place, insert anchor into hole.



4. Using the proper size hammer, set pin with several sharp, square strikes on head of pin until pin is flush with top of anchor. Anchor is now properly set. No need to torque nut.