



SOFTWARE UPDATE INSTRUCTIONS


SOFTWARE UPDATE VIA USB MEMORY STICK & KEYONLINE WEBSITE

WHAT YOU WILL NEED:




To check your current software version, see 'Version SW' below the Main Menu tab


STEP 1: Prepare USB Memory Stick with Update File




At **MAIN MENU**, select **SETUP**




At **SETUP MENU**, select **UPDATES**



Then select **KEYONLINE VIA PC**




Select **YES** to Software Update




Insert USB Memory Stick, select **OK**



USB stick inserts on right side of console



Console prepares software file




Remove USB stick, Select **OK**


STEP 2: Install Update File on USB from PC




Insert USB stick into USB port on PC then go to <http://keyonline.keyline.it>




On site, double-click **CHOOSE FILE**



Go to Computer, then double-click **Removable Disk**




Highlight the '.csk' file listed and click **OPEN**




File now appears in the box on the Keyonline site, click **SUBMIT**




Click **OK** when this screen appears




Software package creation will begin. This take up to a few minutes depending on your Internet speed.



Package creation completed should appear. You will be prompted with a pop up at the bottom of the screen, click on the drop down arrow to the right of 'SAVE' and select 'SAVE AS'




After selecting 'SAVE AS', you will be prompted to select the destination where you want to save the file. Go to Computer, then highlight Removable Disk and select OPEN. The file will begin downloading to the Removable Disk (i.e. the USB memory stick). **NOTE:** The file can take up to 45 minutes to download depending on Internet speed and file size.




Once the update file has finished installing you may exit the Keyonline site and then safely remove the Removable Disk from your drive. To Eject, go to Computer, then highlight Removable Disk and select 'Eject' from the menu bar.

You can now take the USB memory stick back to your console to complete the software update.


STEP 3: Complete Software Installation on Console






Insert USB into console and select **OK**




Update begins




Select **YES** to confirm update



Machine will re-boot and power back up as update continues



Update continues; progress bar on bottom



Update successful; select **OK**